



CD21 電腦枱 S-969
(橫 / 直機均可)
W550 X D490 X H(620+750) mm



CD22 電腦枱 S-979
(橫 / 直機均可)
W550 X D490 X H(620+750) mm



CD23 電腦枱 S-9808
(橫 / 直機均可)
W640 X D600 X H1370 mm




CD24 電腦枱 (可放大列表機)
S-972 W800 X D500 (600+760) mm
S-973 W950 X D500 (710+760) mm



CD25 電腦枱 (可放大列表機)
S-9807 W700 X D480 X (620+750) mm



CD26 電腦枱 WD30
W640 X 500 X H1280 mm



CD27 電腦枱 ED-F95
W650 X D500 X H1280 mm



CD28 電腦枱 WD267
W900 X D560 X H750 mm



CD29 有 / 無捲門電腦枱
WD760 (有捲門)
WD761 (無捲門)
W1250 X D600 X 800 mm



CD30 有 / 無捲門電腦枱
WD660 (有捲門)
WD661 (無捲門)
W1050 X D600 X H80 mm



CD31 電腦枱 WD300
W1200 X D600 X H750 mm



CD32 電腦枱 WD260
W1200 X D600 X H750 mm




CD33 綜合型電腦枱
WD800 橫置式電腦主機
WD900 直立式電腦主機
主枱 W1300 X D600 X H750 mm
移動櫃 W620 X D440 X H550 mm



CD34 G955 大眾型雙機電腦枱
W1240 X D600 X H750 mm



CD35 省位型電腦枱
W600 X D550 X H1200~1300 mm



CD36 弧形電腦枱 S-976ABD
A. W900 X D300 X H450 mm
D. W900 X D360 X H620 mm
B. W900 X D600 X H740 mm




CD37 櫟木色電腦枱 S-9818AB
W750 X D600 X H(1080+750) mm
新款櫟木色



CD38 櫟木色電腦枱
SL-3128 + SL-3130
W800 X D680 X H(700+750) mm




CD39 櫟木色電腦枱
SL-3928 + SL-3930
W1020 X D680 X H(700+750) mm




CD40 電腦枱
A. W48" X D28" X H27"
B. W44" X D28" X H27"




CD41 STEEL DESK 鋼造電腦枱
W700 X D550 X H(550+710) mm




CD42 PRINTER TABLE
(CD-2) 列表機專用枱
W25" X D20" X H29.5"



CD43 PRINTER TABLE
列表機專用枱
W700 X D600 X H680 mm



CD17 FILES TROLLEY
掛電腦文件架
W24" X D19" X H20"



CD44 (CD-18) 掛電腦文件架
A. 2Dr W18.5" X D25" X H32"
B. 3Dr W18.5" X D25" X H45"
C. 4Dr W18.5" X D25" X H60"




CD45 電腦文件櫃
COMPUTER CABINETS




CD46 KEYBOARD DRAWER
枱面鍵盤
W560 X D400 mm



CD47 KEYBOARD DRAWER
枱底鍵盤
W560 X D330 mm



CD48 KEYBOARD DRAWER
旋轉升降式枱底鍵盤
W560 X D360 mm



CD49 KEYBOARD DRAWER
枱底鍵盤
W560 X D330 mm



CD50 HIDDEN MOUSE BOARD
拉出式滑鼠板 (適合各款木枱)
W400 X D230 mm

(凡有 A+B 者, 可單獨購買 B 部份)